

Hygiene- und Hautschutzplan

Desinfektion von autoklavierbarem Material:

z.B. Laborgeräte, Gefäße, GVO-haltiger Abfall, kontaminierte Schutzkleidung

- 1x täglich bzw. bei Bedarf, schließbare Gefäße dabei weit geöffnet halten
- bei 121°C und 3 bar für 20 min **autoklavieren**
- danach Abfall sachgerecht entsorgen, Geräte/Gefäße reinigen, Kleidung waschen

Hautdesinfektion und Hautschutz:

- täglich nach Arbeitsende bzw. bei Bedarf sofort
- Hände mit **Sterillium Classic Pure** oder **70% Isopropanol** für 30 s einreiben
- Danach Hände mit Seife waschen und eincremen:
vor/während der Arbeit mit **Baktolan protect+ pure**, nach der Arbeit mit **Bactolan balm**

⇒ bei Arbeiten mit Adenovirus-Assoziierten Vektorpartikeln (AAV):
2 Handschuhe übereinander tragen!

Prophylaktische Desinfektion von Oberflächen:

z.B. Arbeitsflächen, Fußböden, Geräteoberflächen

- bei Bedarf
- mit einem geeigneten Desinfektionsmittel der VAH-Liste behandeln, z.B. mit:
1% Unigloves: Lösung frisch ansetzen, und nur am selben Tag verwenden;
Flächen damit abwischen und 5 min einwirken lassen
- aus Gründen des Produktschutzes z.B. mit **70% Ethanol** (max. 50 mL/m²):
Fläche abwischen damit abwischen und 5 min einwirken lassen

Dekontaminierende Desinfektion von Oberflächen:

z.B. Arbeitsflächen, Fußböden, Geräteoberflächen

- sofort nach Kontamination/Unfall
- mit einem geeigneten Desinfektionsmittel der RKI-Liste behandeln,
z.B. mit **Bacillo AF** (max. 50 mL/m²): Flächen damit abwischen und 15 min
einwirken lassen (vorrätig in R064)

⇒ bei Arbeiten mit Adenovirus-Assoziierten Vektorpartikeln (AAV):

3.6% Dismozon Plus frisch ansetzen, Flächen abwischen und 15 min einwirken
lassen (muss von der jeweiligen Arbeitsgruppe gestellt werden)

Hygiene and Skin Protection Plan

Disinfection of autoclavable material:

e.g. lab equipment, containers/flasks, waste containing GMOs, contaminated protective clothing

- 1x daily or when required, keep closable vessels wide open
- **autoclave** at 121°C and 3 bar for 20 min
- afterwards dispose of waste properly, clean equipment/containers, wash clothes

Skin disinfection and skin protection:

- daily after work or immediately when required
- rub hands with **Sterillium Classic Pure** or with **70% isopropanol** for 30 s
- then wash hands with soap and apply hand balm:
before/during work: **Baktolan protect+ pure**, after work: **Baktolan balm**

⇒ for work with adenovirus-associated vector particles (AAV):
wear 2 gloves on top of each other

Preventive disinfection of surfaces:

e.g. work surfaces, floors, surfaces of lab equipment

- when required
- use a suitable disinfectant from the VAH list, e.g.:
1% Unigloves: make fresh and use only the same day;
wipe surface and leave on for 5 min
- for reasons of product protection, use e.g.:
70% ethanol: wipe surface and leave on for 5 min (use max. 50 mL/m²)

Decontaminating disinfection of surfaces:

e.g. work surfaces, floors, surfaces of lab equipment

- immediately after contamination/accident
- use a suitable disinfectant from the RKI list, e.g. with **Bacillool AF**:
wipe surface and leave on for 15 min (use max. 50 mL/m²) (stored in R064)

⇒ for work with adenovirus-associated vector particles (AAV):
freshly prepare **3.6% Dismozon Plus**, wipe surface and leave on for 15 min
(must be provided by the work group)